

# BEATPAD 2 MIDI MAP



Switches MIDI MSG												
Pads 1-8	Hot Cue	Velocity	AfterTouch	Auto Loop	Velocity	AfterTouch	Touch FX	Velocity	AfterTouch	Slicer	Velocity	AfterTouch
Deck 1	92,00-07,pp	B2,00-07,pp	A2,00-07,pp	92,08-0F,pp	B2,08-0F,pp	A2,08-0F,pp	92,10-17,pp	B2,10-17,pp	A2,10-17,pp	92,18-1F,pp	B2,18-1F,pp	A2,18-1F,pp
Deck 2	93,00-07,pp	B3,00-07,pp	A3,00-07,pp	93,08-0F,pp	B3,08-0F,pp	A3,08-0F,pp	93,10-17,pp	B3,10-17,pp	A3,10-17,pp	93,18-1F,pp	B3,18-1F,pp	A3,18-1F,pp

Pads (Shift)	Hot Cue	Velocity	AfterTouch	Auto Loop	Velocity	AfterTouch	Touch FX	Velocity	AfterTouch	Slicer	Velocity	AfterTouch
Deck 1	92,40-47,pp	B2,40-47,pp	A2,40-47,pp	92,48-4F,pp	B2,48-4F,pp	A2,48-4F,pp	92,50-57,pp	B2,50-57,pp	A2,50-57,pp	92,58-5F,pp	B2,58-5F,pp	A2,58-5F,pp
Deck 2	93,40-47,pp	B3,40-47,pp	A2,40-47,pp	93,48-4F,pp	B3,48-4F,pp	A3,48-4F,pp	93,50-57,pp	B3,50-57,pp	A2,50-57,pp	93,58-5F,pp	B3,58-5F,pp	A3,58-5F,pp

Pads 1-8	Sampler	Velocity	AfterTouch	Bounce Loop	Velocity	AfterTouch	Jog FX	Velocity	AfterTouch	Slicer Loop	Velocity	AfterTouch
Deck 1	92,20-27,pp	B2,20-27,pp	A2,20-27,pp	92,28-2F,pp	B2,28-2F,pp	A2,28-2F,pp	92,30-37,pp	B2,30-37,pp	A2,30-37,pp	92,38-3F,pp	B2,38-3F,pp	A2,38-3F,pp
Deck 2	93,20-27,pp	B3,20-27,pp	A3,20-27,pp	93,28-2F,pp	B3,28-2F,pp	A3,28-2F,pp	93,30-37,pp	B3,30-37,pp	A3,30-37,pp	93,38-3F,pp	B3,38-3F,pp	A3,38-3F,pp

Pads (Shift)	Sampler	Velocity	AfterTouch	Bounce Loop	Velocity	AfterTouch	Jog FX	Velocity	AfterTouch	Slicer Loop	Velocity	AfterTouch
Deck 1	92,60-67,pp	B2,60-67,pp	A2,60-67,pp	92,68-6F,pp	B2,68-6F,pp	A2,68-6F,pp	92,70-77,pp	B2,70-77,pp	A2,70-77,pp	92,78-7F,pp	B2,78-7F,pp	A2,78-7F,pp
Deck 2	93,60-67,pp	B3,60-67,pp	A3,60-67,pp	93,68-6F,pp	B3,68-6F,pp	A3,68-6F,pp	93,70-77,pp	B3,70-77,pp	A3,70-77,pp	93,78-7F,pp	B3,78-7F,pp	A3,78-7F,pp

P. Button	Deck 1	Deck 2
Hot Cue	90,48,pp	91,48,pp
Auto Loop	90,49,pp	91,49,pp
Touch FX	90,4A,pp	91,4A,pp
Slicer	90,4B,pp	91,4B,pp
Sampler	90,4C,pp	91,4C,pp
Bounce Loop	90,4D,pp	91,4D,pp
Jog FX	90,4E,pp	91,4E,pp
Slicer Loop	90,4F,pp	91,4F,pp

Global Velocity/Aftertouch ON/OFF = SHIFT + HOT CUE

LED MIDI MSG			
Pads 1-8	Hot Cue	Auto Loop	Touch FX
Deck 1	92,00-07,pp	92,08-0F,pp	92,10-17,pp
Deck 2	93,00-07,pp	93,08-0F,pp	93,10-17,pp

Pads 1-8	Slicer	Sampler	Bounce Loop
Deck 1	92,18-1F,pp	92,20-27,pp	92,28-2F,pp
Deck 2	93,18-1F,pp	93,20-27,pp	93,28-2F,pp

Pads 1-8	Jog FX	Slicer Loop
Deck 1	92,30-37,pp	92,38-3F,pp
Deck 2	93,30-37,pp	93,38-3F,pp

Pads (Shift)	Hot Cue	Auto Loop	Touch FX
Deck 1	92,40-47,pp	92,48-4F,pp	92,50-57,pp
Deck 2	93,40-47,pp	93,48-4F,pp	93,50-57,pp

Pads (Shift)	Slicer	Sampler	Bounce Loop
Deck 1	92,58-5F,pp	92,60-67,pp	92,68-6F,pp
Deck 2	93,58-5F,pp	93,60-67,pp	93,68-6F,pp

Pads (Shift)	Jog FX	Slicer Loop
Deck 1	92,70-77,pp	92,78-7F,pp
Deck 2	93,70-77,pp	93,78-7F,pp

P. Button	Deck 1	Deck 2
Hot Cue	90,48,pp	91,48,pp
Auto Loop	90,49,pp	91,49,pp
Touch FX	90,4A,pp	91,4A,pp
Slicer	90,4B,pp	91,4B,pp
Sampler	90,4C,pp	91,4C,pp
Bounce Loop	90,4D,pp	91,4D,pp
Jog FX	90,4E,pp	91,4E,pp
Slicer Loop	90,4F,pp	91,4F,pp

# BEATPAD 2 MIDI MAP



Update - 2015-02-13

EQ CLASSIC	Deck 1		Deck 2	
	Non-Shift	Shift	Non-Shift	Shift
Gain (Knob 1)	B0,4B,pp	B0,0B,pp	B1,4B,pp	B1,0B,pp
High (Knob 2)	B0,4C,pp	B0,0C,pp	B1,4C,pp	B1,0C,pp
Mid (Knob 3)	B0,4D,pp	B0,0D,pp	B1,4D,pp	B1,0D,pp
Low (Knob 4)	B0,4E,pp	B0,0E,pp	B1,4E,pp	B1,0E,pp
Filter	-	-	-	-

EQ FILTER	Deck 1		Deck 2	
	Non-Shift	Shift	Non-Shift	Shift
Gain (Knob 1)	B0,4B,pp	B0,0B,pp	B1,4B,pp	B1,0B,pp
High (Knob 2)	B0,4C,pp	B0,0C,pp	B1,4C,pp	B1,0C,pp
Mid	-	-	-	-
Low (Knob 3)	B0,4E,pp	B0,0E,pp	B1,4E,pp	B1,0E,pp
Filter (Knob 4)	B0,49,pp	B0,09,pp	B1,49,pp	B1,09,pp

EQ SWITCH	
Classic	B4,47,pp
Filter	B4,48,pp

FADER START	Non-Shift	Shift
Line Fader	B0,4F,pp	B0,4F,pp
Fader up	-	90,60,pp
Fader down	-	90,73,pp

Jog FX	Jog CC	Jog CC (Shift)
All Pads off	B0,63,pp	B0,23,pp
Pad 1 ON	B2,00,pp	B2,40,pp
Pad 2 ON	B2,00,pp	B2,40,pp
Pad 3 ON	B2,00,pp	B2,40,pp
Pad 4 ON	B2,00,pp	B2,40,pp
Pad 5 ON	B2,00,pp	B2,40,pp
Pad 6 ON	B2,00,pp	B2,40,pp
Pad 7 ON	B2,00,pp	B2,40,pp
Pad 8 ON	B2,00,pp	B2,40,pp

Note: If any Pad is pressed (9x,10-17,7f) within Jog FX-mode, the Jog Wheel CC will change its command to B2,00,pp.  
If several Pads are pressed, the Jog CC will remain in B2,00,pp unless all pads are pressed again (9x,10-17,pp)

Update - 2015-05-15

P. Button	Shift	
	Deck 1	Deck 2
Hot Cue	90,08,pp	91,08,pp
Auto Loop	90,09,pp	91,09,pp
Touch FX	90,0A,pp	91,0A,pp
Slicer	90,0B,pp	91,0B,pp
Sampler	90,0C,pp	91,0C,pp
Bounce Loop	90,0D,pp	91,0D,pp
Jog FX	90,0E,pp	91,0E,pp
Slicer Loop	90,0F,pp	91,0F,pp